

Release Notes for Cisco UCS Platform Emulator, Release 2.5(1aPE1)

First Published: April 10, 2015 Current Release: 2.5(1aPE1)

This document describes system requirements, new features, images information, known caveats and workarounds for Cisco UCS Platform Emulator, Release 2.5(1aPE1). This document also includes current information that became available after the technical documentation was published.

Use this release notes as a supplement with the other documents listed in the documentation roadmap http://www.cisco.com/go/unifiedcomputing/b-series-doc.

Make sure to review other available documentation on Cisco.com to obtain current information on Cisco UCS Platform Emulator.

Contents

This document includes the following sections:

- Revision History, page 2
- Introduction, page 3
- New Hardware Features, page 4
- New Software Features, page 5
- Known Limitations, page 5
- Open Caveats for Release 2.5(1aPE1), page 6
- Related Documentation, page 7



Revision History

Table 1 shows the revision history:

Release	Date	DescriptionCreated Release notes for Cisco UCSPlatform Emulator, Release 2.1	
2.1(1aPE1)	November 26, 2012		
2.1(1aPE2)	December 20, 2012	Updated release information to support Release 2.1(1aPE2).	
		Updated: New Software Features and Known Limitations	
		Added: CSCud75075	
2.1(1aPE3)	February 21, 2012	Added: CSCud77593, CSCud93243, CSCue20944, CSCud92761, and CSCue27490.	
2.1(2aPE1)	July 25, 2013	Updated release information to support Release 2.1(2aPE1).	
		Updated: New Hardware Features, New Software Features, Known Limitations	
		Added: CSCui24389, CSCue30603 CSCuh85876, CSCue13729, and CSCui21714	
2.1 (3aPE1)	September 11, 2013	Added:	
		New SmartPlay Bundles	
		• New Intel Ivy Bridge Processors	
2.2 (1bPE1)	December 17, 2013	Updated the following information to support UCS PE 2.2(1bPE1)	
		Updated: New Hardware Features, New Software Features, Known Limitations	
		Added: CSCul42638, CSCus90690, CSCul49145, CSCur67155 and CSCum05692	
2.2 (2cPE1)	June 4, 2014	Updated the following information to support UCS PE 2.2(2cPE1)	
		Updated: New Hardware Features, New Software Features, Open Caveats for Release 2.2 (2cPE1)	
		Added: CSCup15041and CSCum09806	

1

Release	Date	Description
2.2(3aPE1)	September 16, 2014	Updated the following information to support UCS PE 2.2(3aPE1)
		Updated: New Hardware Features, New Software Features, Open Caveats for Release 2.5(1aPE1)
2.5(1aPE1)	April 10, 2015	Updated the following information to support UCS PE 2.5(1aPE1)
		Updated:Introduction, New Hardware Features, New Software Features,Known Limitations, Open Caveats for Release 2.5(1aPE1)

Introduction

Cisco UCS Platform Emulator is the Cisco UCS Manager application bundled into a virtual machine (VM). The VM includes software that emulates hardware communications for the Cisco Unified Computing System (Cisco UCS) hardware that is configured and managed by Cisco UCS Manager. For example, you can use Cisco UCS Platform Emulator to create and test a supported Cisco UCS configuration, or to duplicate an existing Cisco UCS environment for troubleshooting or development purposes.



Cisco UCS Platform Emulator, Release 2.5(1aPE1) is a new release which supports only UCSME-4308 chassis and its components. For more information on the feature list, open caveats, and limitations, see the documentation for Cisco UCS Platform Emulator, version 2.2(3aPE1).

Cisco UCS Platform Emulator Virtual Machine Packaging

Cisco UCS Platform Emulator is packaged as a compact virtual machine (VM) with the CentOS open source Linux distribution. This VM can run a Cisco UCS Manager multichassis, multiblade simulation on a laptop or desktop computer and does not require an Internet connection. Cisco UCS Platform Emulator is delivered as a zip file and as an .ova file. The zip file includes the.vmx file. The filename of the zip file includes the Cisco UCS Platform Emulator release number, such as Cisco_UCS_Platform_Emulator_2.5.1aPE1.zip. The file size is approximately 700 to 800 MB.

System Requirements

Before installing Cisco UCS Platform Emulator, ensure the system meets the following requirements:

- 2 GB free RAM
- 20 GB disk space
- 1.8-GHz single CPU
- A Mozilla-compatible browser (Firefox or Google Chrome)
- Java Runtime Environment 1.6 or later. You can download files from http://www.java.com

Virtual Machine Prerequisites

Before installing Cisco UCS Platform Emulator, install one of the following supported virtual machine (VM) hypervisors:

- VMware Player 4.0 and above for Microsoft Windows and Linux
- VMware Workstation 7 and above for Microsoft Windows and Linux
- VMware Fusion 4.0 and above for Mac OS X
- VMware vSphere ESXi 4.0 and above
- Microsoft Hyper-V Server
- Java Runtime Environment Version 1.7

New Hardware Features

Cisco UCS Platform Emulator, Release 2.5(1aPE1), adds support for the following new hardware:

- New UCS Chassis UCSME-4308 is a new chassis for modular servers which supports resource sharing such as adapters and storage. It has a single IOM (UCSME-4308)
- Compute Modular Server -Cisco UCSME-142-M4 Socket Server (UCSME-142-M4)
- DIMM UCS-MU-1X082RY-F
- Storage Disks:
 - UCS-SD240G0KS2-EV
 - UCS-SD480G0KS2-EV
 - UCS-SD960G0KS2-EV
 - UCS-SD400G0KS2-EP
 - UCS-SD800G0KS2-EP
 - UCS-SD16T12S2-EP
- CPUs:
 - UCS-CPU-E31220LD
 - UCS-CPU-E31240LD
 - UCS-CPU-E31275LD
- Storage controller Cisco 12G SAS Modular Raid Controller (UCSME-MRAID12G)

- Changes to the Cisco UCS Platform Emulator VM Console
 - Modifications to the VM Console login
 - Modifications to the VM Console Options Menu
 - Modifications to the Network Settings
 - Modifications to the System Settings
 - More details added to the Status Summary display

New Software Features

This section briefly describes the new features introduced in Cisco UCS Platform Emulator, Release 2.5(1aPE1). For detailed information about the features listed, see the documents listed in the "Related Documentation" section.

Cisco UCS Platform Emulator, Release 2.5(1aPE1) includes the following new features:

- Templates (pre-configured cartridges with servers on the control panel) for new modular servers:
 - ME142 M4 Low
 - ME142 M4 Medium
 - ME142 M4 High
- New tab for modular servers
- Support for storage profile operations:
 - Creation of a Logical Unit Number (LUN)
 - Deletion of a LUN
 - Modification to a LUN
 - Hot Spare addition
 - Removal of Hot Spares

Known Limitations

Cisco UCS Platform Emulator, Release 2.5(1aPE1) has the following limitations:

- **Download of stripped-down version of UCS Firmware** From UCS PE 2.2(1bPE1) onwards, only the stripped-down version of size less than 50 KB is available for download. The download of regular (non-stripped version) version is not supported anymore.
- Recommission and decommission—Chassis and modular server recommission and decommission are not supported.
- **Domain Name Server (DNS) resolution** DNS resolution is not available for Cisco UCS Platform Emulator. All domain names must be resolved manually using a static IP address.
- **Syslog**—Cisco UCS Platform Emulator and Cisco UCS Manager integrated with Cisco UCS Platform Emulator does not produce a syslog.
- **Data path**—Cisco UCS Platform Emulator does not emulate network data flow. The software emulates the functions that are necessary for the management plane.
- XML Export in Google Chrome—The Startup Hardware Configuration user interface allows you to save the XML-formatted hardware configuration to a local computer. This is the client computer that is running the browser. To save the file, click Export Configuration to XML File > Save as... and then save the XML text to a local file. However, If you are using Google Chrome, you must save the file as a .txt file. If you save the file in another format such as .xml, Google Chrome adds unnecessary HTML tags in the saved file produces an incorrect XML format.
- Microsoft Internet Explorer—Microsoft Internet Explorer does not support the Cisco UCS Platform Emulator Model Object Browser and Start-up Inventory features. To use these features, you must use a Mozilla-compatible browsers such as Mozilla Firefox or Google Chrome. Internet Explorer Version 8.0 and later supports other Cisco UCS Platform Emulator features.

- **Cut-through interfaces**—Cut-through interfaces to equipment such as IPMI and SNMP, are not supported. Servers in a Cisco UCS domain contain integrated management controllers (CIMCs), each of which supports an IPMI interface. The fabric interconnect components of Cisco UCS support an SNMP interface. However, because both fabric interconnects and CIMC are considered to be endpoints of the Cisco UCS management system, these interfaces are cut-through interfaces that bypass Cisco UCS Manager, the central management system.
- Serial over LAN, FTP, TFTP, Telnet— Similarly to SNMP and IPMI interfaces, serial over LAN, TFTP, FTP, and Telnet access (through user-facing or management-plane-facing Ethernet interfaces) is not available because they bypass the management software and are considered cut-through access. SSH is supported only to the Cisco UCS Platform Emulator management IP through the config user for Cisco UCS Manager CLI access.
- **Keyboard/Video/Mouse** (KVM)— KVM is a cut-through interface. Cisco UCS Platform Emulator does not support KVM because there are no physical servers attached to the emulation system to which KVM could connect. Launching the KVM console does not display an error message.
- Emulation of high-availability failover— No failover scenario is supported. If one management process dies, the other does not take over.
- AAA-based authentication (LDAP, RADIUS, TACACs)— In emulation mode, Cisco UCS Manager accepts security configuration changes, but does not enforce local or remote password authentication. Any username and password combination can successfully log in to the Cisco UCS Manager GUI with administrator privileges. If a local user is created with a role and locale, Cisco UCS Platform Emulator enforces role, privilege, and locale definitions for the user logging in, allowing an end user to test how roles, privileges, and locales function in Cisco UCS Manager.
- **Remote monitoring** (SNMP, Syslog, Call Home, Smart Call Home)—Cisco UCS Platform Emulator does not support remote monitoring of Cisco UCS Manager on any interface except the Cisco UCS Manager XML API. You can configure SNMP (traps or gets), local or remote syslog, Call Home, and Smart Call Home remote monitoring in Cisco UCS Platform Emulator but you cannot send or query data through those interfaces.
- **Cisco UCS Manager database backup and restore**—Cisco UCS Platform Emulator does not support full- state back up or restore configurations from within Cisco UCS Manager. If a user imports a system backup which consists of switch configurations such as VLAN, CallHome, and so on, the import operation fails.
- **Capability catalog**—Cisco UCS Platform Emulator does not support updating the capability catalog in Cisco UCS Manager. Cisco UCS Platform Emulator supports only the original capability catalog.
- Hardware changes—The following list describes the hardware changes:
 - Cisco UCS Platform Emulator does not support adding or removing hardware, such as servers, chassis, I/O modules, and power supplies, dynamically in the Cisco UCS Platform Emulator control panel. Adding, modifying, or removing hardware in the Cisco UCS Platform Emulator startup hardware configuration requires you to restart the Cisco UCS Platform Emulator application software.

Open Caveats for Release 2.5(1aPE1)

This section lists the open caveats for this release.

Bug ID	Symptom	Workaround
CSCus90690	Pools and policies configured on Cisco UCS Central are not visible in Cisco UCS Platform Emulator in High Availability mode	No workaround.
CSCur67155	Discovery fails for more than 14 fully populated chassis.	No workaround.

Related Documentation

For more information, you can access related documents from the following links:

- Link to bundle images document
- Cisco UCS Documentation Roadmap

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

This document is to be used in conjunction with the documents listed in the "Related Documentation" section.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.