



Release Notes for Cisco UCS Platform Emulator, Release 2.2(4bPE1)

First Published: May 22, 2015

Current Release: 2.2(4bPE1)

This document describes system requirements, new features, images information, known caveats and workarounds for Cisco UCS Platform Emulator, Release 2.2(4bPE1). This document also includes current information that became available after the technical documentation was published.

Use this release notes as a supplement with the other documents listed in the documentation roadmap <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

Make sure to review other available documentation on Cisco.com to obtain current information on Cisco UCS Platform Emulator.

Contents

This document includes the following sections:

- [Revision History, page 2](#)
- [Introduction, page 3](#)
- [New Hardware Features, page 4](#)
- [New Software Features, page 4](#)
- [Known Limitations, page 5](#)
- [Open Caveats for Release 2.2 \(4bPE1\), page 7](#)
- [Related Documentation, page 7](#)



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Revision History

Table 1 shows the revision history:

Table 1 *Online History Changes*

Release	Date	Description
2.1(1aPE1)	November 26, 2012	Created Release notes for Cisco UCS Platform Emulator, Release 2.1
2.1(1aPE2)	December 20, 2012	Updated release information to support Release 2.1(1aPE2). Updated: New Software Features and Known Limitations Added: CSCud75075
2.1(1aPE3)	February 21, 2012	Added: CSCud77593, CSCud93243, CSCue20944, CSCud92761, and CSCue27490.
2.1(2aPE1)	July 25, 2013	Updated release information to support Release 2.1(2aPE1). Updated: New Hardware Features, New Software Features, Known Limitations, Added: CSCui24389, CSCue30603 CSCuh85876, CSCue13729, and CSCui21714
2.1 (3aPE1)	September 11, 2013	Added: <ul style="list-style-type: none"> • New SmartPlay Bundles • New Intel Ivy Bridge Processors
2.2 (1bPE1)	December 17, 2013	Updated the following information to support UCS PE 2.2(1bPE1) Updated: New Hardware Features, New Software Features, and Known Limitations Added: CSCul42638, CSCul28894, CSCul49145, CSCum00462, and CSCum05692
2.2 (2cPE1)	June 4, 2014	Updated the following information to support UCS PE 2.2(2cPE1) Updated: New Hardware Features, New Software Features, Open Caveats for Release 2.2 (2cPE1) Added: CSCup15041and CSCum09806

Release	Date	Description
2.2(3aPE1)	September 16, 2014	Updated the following information to support UCS PE 2.2(3aPE1) Updated: New Hardware Features, New Software Features, and Open Caveats for Release 2.2(3aPE1)
2.2(4bPE1)	May 22, 2015	Updated the following information to support UCS PE 2.2(4bPE1) Updated: New Hardware Features, New Software Features, Known Limitations and Open Caveats for Release 2.2(4bPE1)

Introduction

Cisco UCS Platform Emulator is the Cisco UCS Manager application bundled into a virtual machine (VM). The VM includes software that emulates hardware communications for the Cisco Unified Computing System (Cisco UCS) hardware that is configured and managed by Cisco UCS Manager. For example, you can use Cisco UCS Platform Emulator to create and test a supported Cisco UCS configuration, or to duplicate an existing Cisco UCS environment for troubleshooting or development purposes.



Note

Cisco UCS Platform Emulator, Release 2.2(4bPE1) replaces Release 2.2(3aPE1). You should recreate a new Cisco UCS Platform Emulator VM with the newest Cisco UCS Platform Emulator version to use the latest features.

Cisco UCS Platform Emulator Virtual Machine Packaging

Cisco UCS Platform Emulator is packaged as a compact virtual machine (VM) with the CentOS open source Linux distribution. This VM can run a Cisco UCS Manager multichassis, multiblade simulation on a laptop or desktop computer and does not require an internet connection. Cisco UCS Platform Emulator is delivered as a zip file and as an .ova file. The zip file includes the .vmx file. The filename of the zip file includes the Cisco UCS Platform Emulator release number, such as Cisco_UCS_Platform_Emulator_2.2.4bPE1.zip. The file size is approximately 700 to 800 MB.

System Requirements

Before installing Cisco UCS Platform Emulator, ensure the system meets the following requirements:

- 2 GB free RAM
- 20GB disk space
- 1.8-GHz single CPU
- A Mozilla-compatible browser (Firefox or Google Chrome)
- Java Runtime Environment 1.6 or later. You can download files from <http://www.java.com>

Virtual Machine Prerequisites

Before installing Cisco UCS Platform Emulator, install one of the following supported virtual machine (VM) hypervisors:

- VMware Player 4.0 and above for Microsoft Windows and Linux
- VMware Workstation 7 and above for Microsoft Windows and Linux
- VMware Fusion 4.0 and above for Mac OS X
- VMware vSphere ESXi 4.0 and above
- Microsoft Hyper-V Server
- Java Runtime Environment Version 1.7

New Hardware Features

Cisco UCS Platform Emulator Release 2.2(4bPE1), adds support for the following new hardware:

- Added support for the following network adapters:
 - UCSC-MLOM-C10T-02
 - UCSB-MEZ-BRC-02
 - UCSC-PCIE-C10T-02
- New Fabric Extender N2K-C2232TM-E-10GE added
- Added the following new templates containing UCSC-MLOM-C10T-02 and UCSC-PCIE-C10T-02 adapters:
 - C220M4LMedium
 - C240M4LMedium
- Changes to the Cisco UCS Platform Emulator VM Console:
 - Modifications to the VM Console login
 - Modifications to the VM Console Options Menu
 - Modifications to the Network Settings
 - Modifications to the System Settings
 - More details added to the Status Summary display

New Software Features

This section briefly describes the new features introduced in Cisco UCS Platform Emulator, Release 2.2(2bPE1). For detailed information about the features listed, see the documents listed in the “[Related Documentation](#)” section.

Cisco UCS Platform Emulator, Release 2.2(4bPE1) includes the following new features:

- Added support for the following storage profile operations:
 - Creation of a Logical Unit Number (LUN)
 - Deletion of a LUN
 - Modification to a LUN

- Hot Spare addition
- Removal of Hot Spares

Known Limitations

Cisco UCS Platform Emulator, Release 2.2(4bPE1) has the following limitations:

- **Import from XML**—Adapters and storage controllers are inserted into the PCI slots of rack servers. When an XML before 2.2(4bPE1) version is imported to the 2.2(4bPE1) setup, storage controllers might not be added to rack servers if the storage controller slot is same as the adapter slot. In such cases, storage controllers must be added manually.
- **Download of stripped-down version of UCS Firmware**- From UCS PE 2.2(1bPE1) onwards, only the stripped-down version of size less than 50 KB is available for download. The download of regular (non-stripped version) version is not supported anymore.
- **Import from a running Cisco UCS system and import from XML**—If you import a setup with rack servers, we recommend that the setup is either a true high-availability (HA) or a true stand-alone setup. If there is a mixed configuration then the import may not work.
- **Recommission and decommission**—Chassis and blade server recommission and decommission are not supported. Only rack servers can be recommissioned or decommissioned.
- **Domain Name Server (DNS) resolution**— DNS resolution is not available for Cisco UCS Platform Emulator. All domain names must be resolved manually using a static IP address.
- **Blade server discovery**—When a blade server discovery is complete, performing a power ON/OFF to boot the server is not supported.
- **Blade server configuration error**—A configuration error message is displayed when the configuration includes a Cisco UCS B200 M3 Blade Server and only the Cisco UCS 1240 Virtual Interface Card. The error message displays “Identify Unestablishable”. The blade server configuration will not fail if you include the Cisco UCS 1240 Virtual Interface Card and the Cisco UCS 1280 Virtual Interface Card in the configuration.
- **Syslog**—Cisco UCS Platform Emulator and Cisco UCS Manager integrated with Cisco UCS Platform Emulator does not produce a syslog.
- **Data path**—Cisco UCS Platform Emulator does not emulate network data flow. The software emulates the functions that are necessary for the management plane.
- **XML Export in Google Chrome**—The Startup Hardware Configuration user interface allows you to save the XML-formatted hardware configuration to a local computer. This is the client computer that is running the browser. To save the file, click Export Configuration to XML File > Save as... and then save the XML text to a local file. However, If you are using Google Chrome, you must save the file as a .txt file. If you save the file in another format such as .xml, Google Chrome adds unnecessary HTML tags in the saved file produces an incorrect XML format.
- **Microsoft Internet Explorer**—Microsoft Internet Explorer does not support the Cisco UCS Platform Emulator **Model Object Browser** and **Start-up Inventory** features. To use these features, you must use a Mozilla-compatible browsers such as Mozilla Firefox or Google Chrome. Internet Explorer Version 8.0 and later supports other Cisco UCS Platform Emulator features.
- **Cut-through interfaces**—Cut-through interfaces to equipment such as IPMI and SNMP, are not supported. Servers in a Cisco UCS domain contain integrated management controllers (CIMCs), each of which supports an IPMI interface. The fabric interconnect components of Cisco UCS

support an SNMP interface. However, because both fabric interconnects and CIMC are considered to be endpoints of the Cisco UCS management system, these interfaces are cut-through interfaces that bypass Cisco UCS Manager, the central management system.

- **Serial over LAN, FTP, TFTP, Telnet**— Similarly to SNMP and IPMI interfaces, serial over LAN, TFTP, FTP, and Telnet access (through user-facing or management-plane-facing Ethernet interfaces) is not available because they bypass the management software and are considered cut-through access. SSH is supported only to the Cisco UCS Platform Emulator management IP through the **config** user for Cisco UCS Manager CLI access.
- **Keyboard/Video/Mouse (KVM)**— KVM is a cut-through interface. Cisco UCS Platform Emulator does not support KVM because there are no physical servers attached to the emulation system to which KVM could connect. Launching the KVM console does not display an error message.
- **Emulation of high-availability failover**— No failover scenario is supported. If one management process dies, the other does not take over.
- Configuration of UCSC-PCIE-CSC-02 adaptor
- **AAA-based authentication (LDAP, RADIUS, TACACs)**— In emulation mode, Cisco UCS Manager accepts security configuration changes, but does not enforce local or remote password authentication. Any username and password combination can successfully log in to the Cisco UCS Manager GUI with administrator privileges. If a local user is created with a role and locale, Cisco UCS Platform Emulator enforces role, privilege, and locale definitions for the user logging in, allowing an end user to test how roles, privileges, and locales function in Cisco UCS Manager.
- **Remote monitoring (SNMP, Syslog, Call Home, Smart Call Home)**—Cisco UCS Platform Emulator does not support remote monitoring of Cisco UCS Manager on any interface except the Cisco UCS Manager XML API. You can configure SNMP (traps or gets), local or remote syslog, Call Home, and Smart Call Home remote monitoring in Cisco UCS Platform Emulator but you cannot send or query data through those interfaces.
- **Cisco UCS Manager database backup and restore**—Cisco UCS Platform Emulator does not support full- state back up or restore configurations from within Cisco UCS Manager. If a user imports a system backup which consists of switch configurations such as VLAN, CallHome, and so on, the import operation fails.
- **Capability catalog**—Cisco UCS Platform Emulator does not support updating the capability catalog in Cisco UCS Manager. Cisco UCS Platform Emulator supports only the original capability catalog.
- Configuration of UCSC-PCIE-CSC-02 adaptor The Direct Connect Rack set up allows you to configure the UCSC-PCIE-CSC-02 adaptor only in the SWM slot. A configuration error message is displayed if the adaptor is connected to any other slot of the server.
- **Hardware changes**—The following list describes the hardware changes:
 - Cisco UCS Platform Emulator does not support adding or removing hardware, such as servers, chassis, I/O modules, and power supplies, dynamically in the Cisco UCS Platform Emulator control panel. Adding, modifying, or removing hardware in the Cisco UCS Platform Emulator startup hardware configuration requires you to restart the Cisco UCS Platform Emulator application software.
- **Import from Direct Connectivity set up** - The following list describes the limitations:
 - While importing from Direct Connect Rack set up, the Live Import feature imports only a pure set up (Rack servers are directly connected to the switch with no Fabric Extenders (FEX) or can have a dangling Fabric Extender (FEX) connected only to the switch). If there is a mixed configuration then, the import may fail to work.

- While importing from Direct Connect Rack set up, the Live Import feature imports only the UCSC-PCIE-CSC-02 adaptor connected to the SWM slot of the server. The adaptors configured in other slots may not get imported.

Open Caveats for Release 2.2 (4bPE1)

This section lists the open caveats for this release.

Bug ID	Symptom	Workaround
CSCuu12396	On configuring more than 14 chassis on the control panel, chassis discovery fails.	None
CSCuu19583	When multiple rack servers are configured on the control panel, discovery of rack servers fails occasionally with Cisco IMC vMedia error	Restart UCSPE

Related Documentation

For more information, you can access related documents from the following link:

- [Cisco UCS Documentation Roadmap](#)

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

this document is to be used in conjunction with the documents listed in the “[Related Documentation](#)” section.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

